


User Manual

CORDLESS SCREWDRIVER



Model NO.: DL-CP04-E2B1

HEINLEIN TOOL CO., LTD.
 1610 SOUTH MAIN STREET, MARIETTA, GA 30067
 TEL: 770-429-1100 FAX: 770-429-1101
 WWW.HEINLEIN.COM MAIL: SALES@HEINLEIN.COM

Reserved for future use
 Version: 1.0
 Date: May, 2022

Product Certificate

Inspector: 01

Date of manufacture: _____

4.3. Place a bit into the bit holder of the screwdriver. Select the required direction to rotate the reverse section (which will lock the screwdriver in its central position) and squeeze the trigger to start the screwdriver. The LED spotlight will light with initial pressure on the trigger.
 4.4. To change the position of the handle, press the handle lock and turn the handle 90° until it clicks into position (fig.2).
 4.5. When finished working, remove the bit from the bit holder pulling back the quick-release bit holder if released (fig.1). Clean the screwdriver and wipe the points in the storage case. Store the case in a safe, dry, child proof location.

5. WARRANTY INFORMATION

The warranty period for the cordless tool is considered to be consumable item and is 24 months from the date of purchase.

⚠ **WARNING:** Risk of Hand Arm Vibration (HAV)

The tool may cause Hand Arm Vibration Syndrome if its use is not managed correctly.

This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.

The tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.

Please note that the application of the tool to a task specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emissions is conducted prior to commencing with a specific task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

4.3. Place a bit into the bit holder of the screwdriver. Select the required direction to rotate the reverse section (which will lock the screwdriver in its central position) and squeeze the trigger to start the screwdriver. The LED spotlight will light with initial pressure on the trigger.
 4.4. To change the position of the handle, press the handle lock and turn the handle 90° until it clicks into position (fig.2).
 4.5. When finished working, remove the bit from the bit holder pulling back the quick-release bit holder if released (fig.1). Clean the screwdriver and wipe the points in the storage case. Store the case in a safe, dry, child proof location.

5. WARRANTY INFORMATION

The warranty period for the cordless tool is considered to be consumable item and is 24 months from the date of purchase.

⚠ **WARNING:** Risk of Hand Arm Vibration (HAV)

The tool may cause Hand Arm Vibration Syndrome if its use is not managed correctly.

This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.

The tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.

Please note that the application of the tool to a task specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emissions is conducted prior to commencing with a specific task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

We are not aware of any personal protective equipment (PPE) that provides protection from the risk of hand arm vibration. However, the use of the tool with gloves to enable the operator to remain warm and dry and maintain good blood circulation in the arms, is considered to be the most effective protection in prevention, please refer to the Correct Use and Maintenance section in these instructions.

4.3. Place a bit into the bit holder of the screwdriver. Select the required direction to rotate the reverse section (which will lock the screwdriver in its central position) and squeeze the trigger to start the screwdriver. The LED spotlight will light with initial pressure on the trigger.
 4.4. To change the position of the handle, press the handle lock and turn the handle 90° until it clicks into position (fig.2).
 4.5. When finished working, remove the bit from the bit holder pulling back the quick-release bit holder if released (fig.1). Clean the screwdriver and wipe the points in the storage case. Store the case in a safe, dry, child proof location.

3.6V CORDLESS SCREWDRIVER
 Thank you for purchasing a product. Manufactured to a high standard, this product will, if used according to the instructions below, and properly maintained, give you years of trouble free performance.
IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. THESE INSTRUCTIONS CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual

Wear eye protection

1. SAFETY

- 1.1 GENERAL SAFETY**
 - ✓ Maintain the screwdriver in good condition. Check moving parts against on regular basis.
 - ✓ Keep the screwdriver and charger clean for use and safe performance.
 - ✓ Remove if fitting clothing. Remove ties, watches, rings and other loose items.
 - ✓ Store loose work pieces with a clamp, vice or other adequate holding device.
 - ✓ Avoid unintentional starting.
 - ✓ Wear approved safety eye protection.
 - ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.

✓ Keep children and unauthorized persons away from the working area.
 ✓ Keep screwdriver and charger in a safe, dry, child proof area where the temperature will not exceed 40°C (104°F).
 DO NOT allow children to operate the screwdriver.
 DO NOT hold unsecured work pieces in your hand.
 DO NOT use the screwdriver with your finger on the trigger.
 DO NOT use the screwdriver for a task it is not designed for.
 DO NOT operate the screwdriver in wet conditions or inside the influence of steam, dusts or toxic substances.
 DO NOT use the screwdriver or battery charger wet or in damp or wet locations.

1.2 ELECTRICAL SAFETY FOR USE OF CHARGER

USE ONLY THE SUPPLIED CHARGER FOR CHARGING THE SCREWDRIVER.


- ⚠ **WARNING:** It is the user's responsibility to read, understand and comply with the instructions for use of the supplied charger plug.
- ⚠ **WARNING:** To reduce the risk of burns or fire:
 - DO NOT attempt to open, disassemble, modify or service the battery pack.
 - DO NOT touch, puncture, short external contacts or dispose of in fire or water.
 - DO NOT expose to temperatures above 60°C (140°F).
 - DO NOT dispose of the used battery according to local regulation.
- Forward, back and trigger lock with soft grip handle for comfort and control features locking against adjustment from pistol to straight grip.
- Quick-release 6mm bit holder; infrared LED light to illuminate working area.
- Lithium-Ion battery maintains a high energy density level, has no memory effect, lasting longer than traditional Ni-Cd cells, and will recover from a deep discharge state. Supplied in storage case, with accessories.

to a qualified electrician.
 1.2.3 You must ensure that you inspect the charger plug, cable and connector for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged, DO NOT use. Important: Check that the voltage marked on the charger plug is the same as the power supply to be used.
 Do not use the charger plug from the mains socket by the lead.
 DO NOT use any other type of charger with this product.
 DO NOT use the charger plug outdoors.
 DO NOT use the charger to charge or power any other electrical item.
 DO NOT get the charger wet, or use in wet, damp conditions for indoor use only.

4. OPERATION

- ⚠ **WARNING:** NEVER substitute a standard 3 pin plug, or any other type of plug, into the charger plug.
- ⚠ **WARNING:** NEVER use the charger plug in wet conditions.
- ⚠ **WARNING:** To reduce the risk of burns or fire:
 - DO NOT attempt to open, disassemble, modify or service the battery pack.
 - DO NOT touch, puncture, short external contacts or dispose of in fire or water.
 - DO NOT expose to temperatures above 60°C (140°F).
 - DO NOT dispose of the used battery according to local regulation.
- Forward, back and trigger lock with soft grip handle for comfort and control features locking against adjustment from pistol to straight grip.
- Quick-release 6mm bit holder; infrared LED light to illuminate working area.
- Lithium-Ion battery maintains a high energy density level, has no memory effect, lasting longer than traditional Ni-Cd cells, and will recover from a deep discharge state. Supplied in storage case, with accessories.

3. SPECIFICATION
 Battery:3.6V 15Ah Lithium-Ion
 Charging Time:15-20hrs
 Max Torque:3200nm
 No-load Speed:3200rpm
 Working Capacity:150 pcs
 Weight:1.2kg
 Voltage:18V DC
 Motor Power:610W
 Working capacity: screw screws on wooden board
 4x30mm screws-150 pcs



- 4.1. To charge the screwdriver, insert the charger plug into the charging socket near the base of the screwdriver handle and plug the charger into a mains socket.
- 4.2. The indicator light (fig.2) will illuminate to indicate the battery is being charged. When charging is complete indicator light will be green, unplug the charger from the mains and the screwdriver.

WEEE REGULATIONS

 At the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE), when the product is no longer required, it must be disposed of in an authorised manner. For more information, please contact your local waste authority for recycling information.

ENVIRONMENTAL PRECAUTION

 Avoid environmental disposal of this product in a landfill, incineration or other means of disposal. This product should be taken to a recycling centre and disposed of in a responsible manner. When the product becomes completely unrepairable and requires disposal, please refer to the instructions on the product and packaging for disposal information.

BATTERY REMOVAL

 Under the Union Batteries and Accumulators Regulations (2006/66/EC), this product contains batteries (as defined within those regulations).

No.	Part Name	QTY
1	Gears Box Set	1
2	Left Housing	1
3	Motor Set	1
4	Right Housing	1
5	Screw 2.9x14	30
6	Right Trigger	1
7	Right Trigger Housing	1
8	Frontal and Reverse Switch	1
9	LED Light	1
10	Left Handle Housing	1
11	Switch Trigger	1
12	PCB	1
13	Battery	1
14	Right Handle Housing	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.
 There may be alternative versions of this product, please contact us should you require this information.
 The product shown in this manual is accepted for import use of product. Spare parts must be ordered by a competent person.



Parts Information:
Cordless Screwdriver 3.6V Lithium-Ion